

The SFA32 is a stand-alone state of the art Planter Monitor. It has been designed with features that will give you complete confidence that your planter is performing properly in the field. The SFA 32 is adaptable to most existing harnesses and a wide variety of sensors found on current as well as older planters.

Why trust an older outdated planter monitor that gives you minimal information for your critical planter operations? The SFA 32 provides the operator an instant and on-going visual indication that your planter is operating properly. The easy to read and easy to use SFA 32 will take the stress out of your spring planting season.



Simple Programming & User Interface!

Numerous features – including:

- 7 Inch Color Touch Screen Display for ease of viewing & screen navigation
- Display gives instant visual indication for each row (Planter Average, low, high)
- Displays Planter Singulation in percent, as well as the percent of Doubles & Skips
- Bar graph for each row so problems can be spotted quickly
- Utilize your current speed sensor
- Display will alarm & bar graph turns red when a row population exceeds the pre-programmed Hi/Lo Limits
- Seeds per acre displayed for each row
- Monitors up to 32 rows
- Readout of MPH plus 3 resettable acre counters
- If the row plugs or fails to drop seed, the display will show both visually and by audio alarm which row has a problem



Precision Sensors



Ag Express GVS Speed Sensor

Display Examples:

Home		Seeds	Setup		Alarm 1 of 1				
Population (Seeds/Acre)		Spacing (inches)		Acres 1		Acres 2		Acres 3	
Avg		Avg		965		1321		1321	
29.7		11.8		Acre/Hr		Singulation (%)		Skips 1.0	
Min (4)		Min (1)		18.2		96.5		Doubles 2.4	
13.4		11.8							
Max (1)		Max (1)							
31.2		11.8							

Seed Singulation

Home		Seeds	Setup		5.0 MPH		
Row		Seeds/Acre		Avg		Select Seeds View	
3		31.2		31.2			
							
1	2	3	4	5	6	7	8
10	11	12					

Row 3 Population


Home		Seeds	Setup		5.0 MPH				
Row		Min		Max		Avg		Select Seeds View	
1		31.0		31.0		31.0			
									
1	2	3	4	5	6	7	8		
10	11	12							

Min/Max/Avg Screen

Home		Seeds	Setup		Alarm 1 of 1		
Row		Seeds/Acre		Avg		Select Seeds View	
3		31.2		31.2			
							
1	2	3	4	5	6	7	8
10	11	12					

Row 5 Failure

Note: The SFA can also be used as a combination Flow Meter/ Planter Monitor unit!



106 West Main
Sulphur Springs, IN 47388
(765) 533-4809
ss@agexpress.com

6280 NE 14th Street
Des Moines, IA 50313
(515) 289-2746
dsm@agexpress.com

308 Claude Road
Grand Island, NE 68803
(308) 381-2905
gi@agexpress.com

www.agexpress.com